













214-BB

Návod k montáži




<p>A 23 sad</p> 	<p>B 11 ks</p>  <p>Ø 8*40</p>	<p>C 4 ks</p> 
<p>D 42 ks</p>  <p>Ø3*14</p>	<p>E 2 ks</p> 	<p>F 3 ks</p> 
<p>G 6 ks</p>  <p>L 20mm</p>	<p>H 2 sady</p> 	<p>I 2 ks</p> 
<p>J 4 ks</p> 		


1





2




3



4



5



6

